

# ADI-524

The ADI-524 is **4 channel 4-20mA** analog to RS485 converter using standard Modbus-RTU protocol. It has dedicated RS485 port for output which need power supply to lit up device or It can work over single USB port having power supply and RS485 output in it.

Please read carefully before starting. Also read the product [safety information](#).

- [General information](#)
- [Configuration Manual](#)
- [Protocol Description](#)
- [Safety information](#)

# General information

<a href="#">Download technical specification</a>	<a href="#">Technical Specification</a>
--	---

ADI-524 has **4 opto-isolated analog inputs** and RS485/USB output. It is also featured with isolated 24V power output to feed 4-20mA sensors/devices. For baud rate and Modbus address configuration to be done using DIP switch.

Additional USB port make this device perfect to use with industrial computers and gateways having dedicated USB port, as this product is designed according to industry-standards.


It can be mounted on standard DIN rail by using clamps.

## Hardware informations


This interface converted is made of single PCB, which is fitted in aluminum housing. The housing is made of a thick, strong aluminum profile with two end plates also made from aluminum. The surface of the housing is finished by anodizing.

At the bottom of the housing there are slots through which DIN rail clamp or any other clamp can be mounted by t-nuts.

## Front view dimensions




Side view dimensions




## Interfaces

Top view connector and indicators



Bottom view connector




# Configuration Manual

Please read carefully before starting. Also read the product safety information.

## Wiring and connection

The ADI-524 can be powered from a DC power supply in the range of 8-36V. Also, it can be powered from the USB port of a computer or IoT gateway. Both power sources can be connected simultaneously without fear of damage.



In order to connect sensors with a 4-20mA output, it is necessary to provide them power in the loop. Here are some possible connection methods. Either the built-in isolated 24V power supply can be used or an external current loop power supply can be used.


All current inputs marked as - on the housing are connected together. The isolated 24V, on the other hand, has no galvanic connection to any of the inputs.

---

## Connection Diagrams


## Built-in 24V

Connection of four RTD converters using the built-in 24V power supply.



## External 24 V

Connection of four RTD converters using the external 24V power supply.



# Modbus configuration

It is necessary to set the serial port parameters and the Modbus address using the DIP switch before powering on the device. (reference table for both are given below)

Make sure to reboot/restart device irrespective of any change in DIP switch to be reflected in hardware

## MODBUS Serial Port Parameter

Parameter	Option/range
Baudrate	9600 – 115200 configurable



Parameter	Option/range
ata bit	8
Parity	None
Stop bit	1

## MODBUS Baudrate Configuration

User can set the baud rate using 2 Bit DIP switch. This allows to set baud rate between 9600bps to 115200bps as shown below table.

Baudrate	SW1	SW2
9600	OFF	OFF
19200	ON	OFF
38400	OFF	ON
115200	ON	ON

After setting up the switch, it is necessary to restart the ADI by disconnecting the power supply and, if using USB power, to disconnect it.

## MODBUS Address configuration

User can set the slave ID address using 4 Bit DIP switch. This allow 0 to 15 different IDs to be set. The number below the switches are added together and the result will be identifier of the device slave ID.

Slave ID	SW3	SW4	SW5	SW6
1	OFF	OFF	OFF	OFF
1	ON	OFF	OFF	OFF
2	OFF	ON	OFF	OFF
3	ON	ON	OFF	OFF

Slave ID	SW3	SW4	SW5	SW6
4	OFF	OFF	ON	OFF
5	ON	OFF	ON	OFF
6	OFF	ON	ON	OFF
7	ON	ON	ON	OFF
8	OFF	OFF	OFF	ON
9	ON	OFF	OFF	ON
10	OFF	ON	OFF	ON
11	ON	ON	OFF	ON
12	OFF	OFF	ON	ON
13	ON	OFF	ON	ON
14	OFF	ON	ON	ON
15	ON	ON	ON	ON

# Protocol Description

## Overview

The MODBUS protocol is a widely used communication standard in industrial automation, facilitating master-slave data exchange. It is known for its simplicity and flexibility, making it suitable for a range of applications in connecting intelligent devices.

In MODBUS communication, messages sent from the master to a slave device contain key components: the slave's address, a command (such as "read register" or "write register"), the associated data, and an error-checking field (using LRC or CRC for checksum). As a messaging protocol, MODBUS is independent of the underlying physical layer, meaning it can be implemented over various mediums like RS485 or USB-to-serial interfaces.

## USB interface

ADI-524 has a built-in USB to serial converter, you can plug USB cable and start device configuration as there is no need to install any additional drivers on most operating systems. However, if you find that you need to install drivers, you can download driver - [.V1.00 driver.zip](#)

The ADI-524 allows operation via only one interface at a time. Either RS485 or USB. DIP switch settings are necessary when using both interfaces

## MODBUS RTU Framing

The ADI-524 module supports standard RTU Modbus protocol for getting the input status and setting/getting the relays status. RTU Modbus Protocol frame is illustrated below:

Start	Address	Function	Data	RC Check	End
≥ 3.5 Char	4 Bits	8 Bits	N*8 Bits	16 Bits	≥ 3.5 Char

- Start Address:** This identifies the specific device or slave on the network. Each device has a unique address to differentiate it from others.
- Function Code:** Specifies the type of operation being requested. Common function codes include:
  - 0x03: Read Holding Registers
  - 0x06: Write Single Register
  - 0x10: Write Multiple Registers
- Starting Address:** The address of the first register from which data will be read or to which data will be written

4. **Number of Registers:** Indicates how many registers should be read or written, starting from the specified address.
5. **CRC (Cyclic Redundancy Check):** This is a checksum used to verify the integrity of the data. It is calculated based on the previous fields and helps detect errors in the transmitted data.

Each part of the request plays an important role in ensuring the correctness of Modbus communication. The start address and function code define the operation, and the CRC checksum protects the accuracy of the message.

## MODBUS Command examples

04 function code for reading value from input.  
Modbus dear query message

Command: read analog input 1		
Byte	Byte description	Example (HEX)
0	Slave ID	01
1	Function code	04
2	Starting address High	00
3	Starting address Low	00
4	Number of Registers High	00
5	Number of Registers Low	02
6	CRC AB	71
7	CRC CD	CB

Start	Slave address XX	Function code 04	Starting Number				CRC ABCD 71 CB	End
			High	Low	High	Low		
			00	00	00	02		

Modbus response

Response: Analog Input - 13.40mA		
Byte	Byte description	Example (HEX)
0	Slave ID	01
1	Function code	04
2	Byte Count	04

Response: Analog Input - 13.40mA		
Byte	Byte description	Example (HEX)
3	Data 1	41
4	Data 2	6C
5	Data 3	CC
6	Data 4	CD
7	CRC AB	BB
8	CRC CD	30

The number in 32-bit floating point HEX format 0x416CCCCD in decimal is: 13.40

Start	Slave address XX	Function code 04	Number of bytes	Data				Error check	End
				First register		Second register			
				Data 1	Data 2	Data 3	Data 4		

# Safety information

## Operating environment

- The device is designed to be installed in clean, dust-free and insect-free places
- Operating temperature: -25 ~ 65°C (-13 ~ 149°F).
- Humidity range is 10% to 95% (non-condensing). Use the device in a dry environment.
- Away from heat sources and direct sunlight.
- It must not be exposed to acid fumes, salts and other chemicals.
- The device must not be used in places where there is a risk of gas explosion.

Use in inappropriate conditions may damage the device or shorten its life.

## Electrical and power supply safety

- The device is powered with a voltage in the range of 8-36V. Voltage up to 24V is considered safe. Be especially careful when supplying them with higher voltages.
- Use only approved accessories
- Use the supplied power adapter or a good quality certified power adapter with the correct supply voltage range and sufficient power.
- Only use approved accessories like antenna etc.

Only a person with qualification and appropriate knowledge should install the device.

## Malfunctioning and damaged device

- Do not disassemble the device.
- Only qualified personnel must service or repair the device or its accessories.
- If water or other liquid has got into the device, or if it looks mechanically damaged, do not connect the device, but take it to an authorized service center.

## What to do and what not to do

- You are solely responsible for the use of the device and any consequences of its use.
- Do not store or use the device in harsh environments such as dust, gases, oils, chemical vapors and damp places.
- Do not throw the device and its accessories. Handle with care.
- The device heats up during operation. Ensure proper ventilation.

- If you need to dispose of your device, check your local regulations for recycling and disposal of electronics.
- Route power, Ethernet, and antenna cables properly so that they cannot be accidentally pulled out.
- The device should be used and kept away from small children.