

Configuration Manual

Please read carefully before starting. Also read the product [safety information](#).

First start

After unpacking, the gateway is ready to use, but requires configuration to adapt to the required functions.

Power supply

First, connect the power supply according to the [power supply](#) information.

Opening inbuilt website

Through the WAN interface

To access the built-in website, connect the gateway by WAN to the local network and enter the DHCP assigned IP address in the address window of the browser. Please note that it may take some time from powering on to booting up the system. When the LEDs next to the RJ45 socket start flashing, after about 10 seconds the built-in website becomes available.

user name: **root**

password: **root**

Through the LAN interface

Connect the ETH2 directly to the computer and enter in the address window of the browser default IP of Gateway.

IP: **192.168.1.60**

user name: **root**

password: **root**

Through the WiFi interface

By default, the gateway creates its own network with default ESSID "AG-702". The network is secured with default password "atreyo12".

Connect to this network and enter the IP in the address bar of your browser.


IP: **192.168.1.1**

user name: **root**

password: **root**




After logging in, you are automatically taken to the dashboard page.




Password setting

At the top there is a message that no password has been set.



Set a password on the **system>administration** page:



To maintain security, it is recommended to use long and complex passwords.

Cellular modem

Modem

The Gateway in its basic configuration is equipped with an LTE modem that also supports GPRS and SMS functions. Different modems were used depending on the model variant. Here is a table of models.

SIM card

The Gateway supports two nano SIM cards, both 1.8V and 3V. The card connector is tray type. When installing the SIM card, pay attention to the correct insertion of the card. The used SIM card tray is designed so that the card sticks to the tray. This make easily insert the SIM regardless of the position of the Gateway


Using Cellular Network

To activate the LTE modem, go to **Network > Interfaces** and select the lte tab there.


Mostly the network operator requires you to enter the APN, sometimes it also requires a username and password. Enter the required data and save.

The screenshot shows the 'General Settings' tab for the 'LTE' interface. The 'Status' section displays 'Device: 3g-lte', 'RX: 0 B (0 Pkts.)', 'TX: 0 B (0 Pkts.)', and an error message 'Error: Network device is not present'. The 'Protocol' is set to 'UMTS/GPRS/EV-DO'. The 'Bring up on boot' checkbox is checked. The 'Modem device' is set to '/dev/ttyUSB2'. A red box highlights the 'Service Type' (set to 'LTE'), 'APN' (set to 'INTERNET'), 'PIN' (empty), 'PAP/CHAP username' (empty), and 'PAP/CHAP password' (empty) fields. The 'Dial number' is set to '*99***1#'. At the bottom right, there are 'DISMISS' and 'SAVE' buttons.

Then go to **System > Custom Commands** and click on Start modem with SIM1/Start modem with SIM2. Depending on which SIM card you want to start.



The modem will start up and connect to the Internet. To check if it is working properly and what the signal is, go to Modem > Information about 3G/4G/5G connection. When the modem starts up, the LEDs showing the signal strength will also light up. This makes it easy to see the signal strength in a particular location.



Cellular modem ON on start

To make the gateway automatically connect to the Internet after startup, you need to add a modem startup in the System > Startup section under Local Startup, add a line before line 'exit 0'. **/usr/commands/start_modem_sim1.sh or /usr/commands/start_modem_sim2.sh**. Then save

the changes. After each reboot, the gateway will automatically start the modem with the selected SIM card.

SMS

To test the SMS operation, the gateway has an SMS interface installed. Under **Modem > SMS Messages**. There you can check sent and received SMS. Be sure to enter the phone number together with the country prefix, but without the + sign. The maximum number of characters is 160. The system does not support alphabets such as devanagari. The maximum number of messages in the inbox is 20.

The screenshot shows the AG-702 web interface. On the left is a sidebar menu with options: Dashboard, Status, System, Modem (selected), Information about 3G/4G/5G connection, SMS Messages, Services, Network, VPN, Statistics, and Logout. The main content area is titled 'SMS Messages' and has tabs for 'Received Messages' (selected), 'Send Messages', 'USSD Codes', 'AT Commands', and 'Configuration'. Below the tabs, there's a note: 'Web UI for receiving messages via sms_tool. More information about the sms-tool on the eko.one.pl forum.' A section titled 'Received Messages' shows a table with columns: From, Received, and Message. The table contains two entries: one from '91' received on '2023-12-22 12:07' with the message 'Yes. System working ok.', and another from '91' received on '2023-12-22 12:06' with the message 'Test reply'. At the bottom right are buttons for 'REFRESH SMS' and 'DELETE MESSAGE(S)'.

For send SMS go to **Send Message** tab.

The screenshot shows the AG-702 web interface with the 'Send Messages' tab selected. The sidebar menu is the same as in the previous screenshot. The main content area is titled 'SMS Messages' and has tabs for 'Received Messages', 'Send Messages' (selected), 'USSD Codes', 'AT Commands', and 'Configuration'. Below the tabs, there's a note: 'Web UI for sending messages via sms_tool. More information about the sms-tool on the eko.one.pl forum.' A section titled 'Send Messages' contains a form with the following fields: 'User Phonebook:' with a dropdown arrow, 'Send to:' with a text input containing '91', 'Message text:' with a large text area containing 'Testing SMS system.', and 'Status:' with a text input. A 'SEND MESSAGE' button is at the bottom right. At the very bottom of the page, there is a footer line: 'Powered by LuCI Master (git-23.175.80454-1d5440a) / ArgonTheme v2.2.9.4 / Atreyo-OpenWrt 1.01.221019 unknown'.

System statistics

The gateway has a built-in real-time statistics system under Status > Realtime Graphs and accurate statistics with selectable time range under Statistics > Graph. You can check CPU load,

memory usage, network load, etc.

Realtime Load




Statistics Interfaces



Statistics Memory

AG-702

- Dashboard
- Status
- System
- Modem
- Services
- Network
- VPN
- Statistics
- Graphs
- Setup
- Logout



Statistics Processor

AG-702


- Dashboard
- Status
- System
- Modem
- Services
- Network
- VPN
- Statistics
- Graphs
- Setup
- Logout



Statistics System Load

AG-702

- Dashboard
- Status
- System
- Modem
- Services
- Network
- VPN
- Statistics
- Graphs
- Setup
- Logout




Modbus

The Gateway has a very advanced Modbus application with a convenient graphical interface. Below are the capabilities of the application:

- Modbus TCP/IP and Modbus RTU support.
 - Any number of serial ports
 - Support for external USB/serial interfaces
 - JSON, TCP/IP and MQTT string formation
 - Data logging in the event of no connection to a server
 - Storage of all data in internal memory
- A detailed guide to Modbus configuration is available [here](#).

Using the terminal

The AG-702 has a built-in bash terminal. With it you can execute all commands in the OpenWRT system. To enter the terminal, go to the tools > terminal section on the built-in website. The default password is the same **root/root**.



Reset and default

Make factory default

To reset the system to factory settings, hold down the "Default/Reset" button for more than 5 seconds while the device is operational. During the factory reset, all LED indicators will light up for 2 seconds.

Reset device

To restart the gateway without disconnecting the power supply, press and hold the "Reset/Default" button for less than 5 seconds. During the restart, 4 LED indicators will light up for 1 second (IN-1, IN-2, RS485, RS232)

Do not hold the button for more than 5 seconds, as it will trigger the gateway to restore default settings.

Revision #27

Created 15 February 2025 16:52:10 by Admin

Updated 9 March 2025 10:00:42 by Admin