

Configuration manual

Connect the correct power supply. You can choose the right power supply in the power supply section.

Then connect the LAN cable to the gateway to the router. It is important that the IP address is in the range of 192.168.10.xxx.


To enter internal website of Gateway make proper LAN connection and in browser address tab enter Gateway IP. The default IP is:

192.168.10.50.

User name: **atreyo**

password: **atreyo.**

In the main menu there are tabs with settings sections.



- A, B, C – for digital outputs
- Req – request modbus device
- Req. dev. – request modbus device

- Devices – RTU configurations devices
 - Serial – configuration serial communication
 - Permission – permission configuration for mobile numbers
 - Guard – for monitoring communication and activity
 - GSM – GSM, LTE, GPRS configuration like APN, password etc.
 - Server – server configuration
 - Ethernet – Ethernet configuration
 - Update – upload firmware and remote update configuration
 - Options – for date, time, location, default etc.
 - Config – backup, restore and remote configuration.
 - Access – access configurations for internal website
 - Info – main page with information about model, firmware version etc.
-

Ethernet

The LAN interface use standard RJ45 8 pin connector with LED indicators. The connector support PoE class A, with power supply range 8-36V DC. If we use screw terminal power connector to power the device the LAN line is protected against back voltage from device. The device is protected from reverse power polarity. If unknowingly it is reverse connected, the Gateway will not work, but will not be damaged. Follow the diagram of connection.

Configuration of Ethernet

Ethernet configuration for LAN. Default value is:

IP = **192.168.10.50**

Mask = **255.255.255.0**

Gateway = **192.168.10.1**

DNS1 = **8.8.8.8**

DNS2 = **8.8.4.4**

A

B

C

Req.

Req. dev.

Devices

Serial

Permission

Guard

Cellular

Server

Ethernet

Update

Options

Config

Access

Info

Ethernet



Ethernet configuration

IP: 192.169.10.50

Mask: 255.255.255.0

Gateway: 192.158.10.1

DNS1: 8.8.8.8

DNS2: 8.8.4.4

Save ethernet

LTE modem

Gateway has inbuilt LTE modem with support of LTE and GPRS.

SIM card


The device support microSIM with voltage 1.8 and 3V. The card holder is push-in/push-out type. Ensure inserting SIM card in proper direction according to the illustration.

Antenna

The device has two female SMA connector for LTE/GSM antenna and for GPS antenna. For proper working it is necessary to connect LTE + GSM band antenna and proper GPS antenna. Antenna line is 50Ω type. Do not switch on device without antenna connected. For better connectivity in remote area it is necessary to use high gain antenna and place it outside of electrical panel box.


Cellular network configuration

Configuration for mode of connection. Default is auto. But if you are using a SIM card that has only GPRS available, set the connection type to GPRS. If it has only LTE then select LTE and if it has both then you can leave it at auto.




The form is titled "Cellular network mode selection" in a dark teal header. It features a label "Operating mode" followed by a dropdown menu. The dropdown menu is open, showing three options: "Auto" (selected with a checkmark), "GPRS", and "LTE". Below the dropdown is a green button labeled "Save mode".

GSM configuration include: APN, user and password.



The form is titled "APN user and password" in a dark teal header. It contains three input fields: "APN:" (empty), "User:" (containing the text "empty"), and "Password:" (containing the text "empty"). A green button labeled "Save GSM parameters" is located at the bottom right.

Gateway phone number is Gateway SIM card phone number. It is not necessary to provide this, but in future this information is accessible by TCP/IP and for maintenance is good practice to add this number.



The form is titled "Gateway phone number" in a dark teal header. It features a label "Device phone number:" followed by an input field containing the text "empty". A green button labeled "Save device phone number" is located at the bottom right.

Cellular network testing is for testing of SIM card and network. You can add your number and Gateway will call or send SMS to this number. For this purpose, call and SMS support must be enabled with the mobile operator.

Testing call and SMS service

Enter the phone number:

Send SMS status

Make a call

Modem data log

...

GNSS

The gateway has a built-in GNSS module which is used as a source of accurate time and location. GNSS settings are known in the LTE modem settings tab

Manual GPS

The location is needed for the solar timer system. In some situations, the gateway is placed in such a location that it does not catch the GNSS signal, and for this purpose there is a manual GPS option. To use this option, you need to enter the longitude and latitude manually.

Powering the active GNSS antenna

The gateway has the ability to accommodate both passive and active GNSS antennas. The supply voltage of the active antenna is 3.3V. To enable the power supply, select Antenna power supply ON.

GPS localization of gateway

Manual GPS

OFF

▼

Latitude:

23.033537

Longitude:

72.524789

[Find out how to enter coordinates](#)

[Atreyo headquarter Latitude:23.033537, Longitude:72.524789](#)

Save GPS options

RS485 – Modbus

The device has opto-isolated RS485 interface with support of Modbus RTU. It is dedicated to energy meter, voltage meter and any Modbus device like PLC which support Modbus RTU protocol. The device supports multiple Modbus devices with separate address range. It is possible to directly send and receive any value of register from server. Please follow proper connection of A and B signals from device to A and B signals in power meter. If the polarity is reversed there will be no data transmission. All modbus configuration like baud-rate, parity, address available in internal website.

Serial Configuration

In this section are RS485 parameter configuration: baud rate, data bit, parity and stop bit.

Parameter	Option/range
Baud-rate	2400 to 460800
Data bit	8, 9
Parity	None, Even, Odd
Stop bit	1, 1.5, 2

Serial interface configuration

Baud

2400

▼

Data Bit

8

▼

Parity

None

▼

Stop Bit

0,5

▼

Save serial

Req. dev. – Request device log

In this section is visible log of modbus devices. In this tab is optional feature to make support for Selec® company meter without necessity to set modbus device details. In window the reply from Selec® device will be visible. Now 2 models of meters are supported MFM383 and EM2M.

Request selected Modbus device

Select device type:

SELEC MFM383

▼

Device modbus address:

...

Devices – Modbus devices

Modbus devices configuration of modbus devices connected to Gateway. Configuration of: device ID, register, endian, start address, offset address, registers, timeout. It can add multiple devices up to maximum 16.

Sn	Parameter	Details information
1	Use	To activate device configuration
2	Modbus Device ID	The ID of modbus device. 01 up to FF
3	Register structure	8 bit UINT, 16 bit UINT, 32 bit UINT, 8 bit INT, 16 bit INT, 32 bit INT, 32 bit float, 16 bit HEX, 32 bit HEX, Array HEX
4	Endian Structure	ABCD, BADC, CDAB, DCBA
5	Start address	First Modbus register address

Sn	Parameter	Details information
6	Offset address	Offset address for add or subtract of actual query address, according to slave device data storage system
7	Number of registers	How many registers needed to query
8	Timeout [ms]	Response time-out for query

Modbus RTU devices configuration

Use	MODBUS Device ID	Register structure	Endian structure	Start address	Offset address	Number of registers	Timeout [ms]
☒	12	8 bit UINT ▾	ABCD ▾				
☒	15	8 bit INT ▾	ABCD ▾				
☒	17	8 bit UINT ▾	ABCD ▾				
☒	323	✓ 8 bit UINT 16 bit UINT 32 bit UINT 8 bit INT 16 bit INT 32 bit INT 32 bit float 16 bit HEX 32 bit HEX Array HEX	ABCD ▾				
☐							
☐							
☐							
☐							
☐							
☐							
☐							

Example


Example for query: 01 04 00 00 00 28 F0 14
 In this example F0 14 is checksum CRC-16 big endian.

Modbus RTU devices configuration

Use	MODBUS Device ID	Register structure	Endian structure	Start address	Offset address	Number of registers	Timeout [ms]
☒	01	32 bit float ▾	CDAB ▾	30001	30001	40	900-
☐							
☐							
☐							

Digital inputs

The device has 2 opto-isolated up to 2500Vrms digital inputs with separate minus signal. The signal maximum voltage is 30V DC. Inputs support only DC signal with proper polarisation. The input digital high is from 3.5V to Vmax, and digital low from 0 to 2V. Inputs can be controlled also by open collector circuit with common positive. The input resistance is approx 2.7k. The input terminal diagram is as per below.



1+/2+ = digital input positive

1-/2- = digital input negative

If by mistake reverse polarity signal is connected to input the input will not work, but will not be damaged.

Digital input status

The status of the inputs can be checked in the tab **info>state** of input.

STATE OF INPUTS

A:

B:

Refresh

Users - passwords

Password configuration

This section is for internal website access. Default password is **atreyo**.

Change password

User:

Password:

empty

New password:

empty

Retype new password:

empty

Save

User configuration

For user change. Default user is **atreyo**.

Change user name

User:

Password:

empty

New user name:

empty

Retype new user name:

empty

Save

Permissions and role

This tab is for permissions of mobile numbers to protect from unauthorised access via SMS commands. By default any number can access Gateway but after input of any number only number from list is able to control Gateway. Mobile number has roles of "**normal**" and "**emergency**". Normal role allow to make control of Gateway, and emergency in addition is the emergency number for alerts. In AG-831 digital inputs high status is event for emergency SMS. It is possible to add maximum 13 telephone numbers. Number format with + before country prefix.

Mobile number role configuration

Phone number	Status
+91997636283445	✓ Normal Emergency Normal
	Normal

System

Multi-function reset button

The AG-811 has multifunction reset button. This button is used to:

- reset device
- restart device
- make default configuration

Multi-function reset button

The AG-811 has multifunction reset button. This button is used to:

- reset device
- restart device
- make default configuration

Press and hold the reset button	Behaviour	Remark
1 to 10 seconds	power off	If device is using battery backup
10 to 20 seconds	restart device	
20 to 30 seconds	make default	
30 and more than 30	exit	

Firmware update

The Gateway can update firmware from remote URL and locally direct by uploading BIN file with proper firmware. To load firmware click load firmware file and select firmware. After loading Gateway will automaticity restart. Firmware update in normal condition will not reset configuration.

Local update

Upload firmware locally

...

Click to load firmware file

Update from server

Update remotely from the server

Update file URL:

Update

Save parameter

Backup / restore config

The gateway allows you to backup your configuration and also upload the configuration to the gateway. To do this, you need to enter the config section.

Local backup/restore

Backup configuration

[Download configuration file](#)

Restore configuration

...

Click to select configuration file

Configuration from server

Also, it is possible to download the configuration from the server. To do this, enter the correct address of the server and the configuration file.

Configuration from server

Config file URL:

Get configuration from URL

Save config URL

Revision #2

Created 2025-03-01 17:07:12 UTC by Yogesh

Updated 2025-03-01 17:23:48 UTC by Yogesh